

# Technical Bulletin

HAMMOND ORGAN

"music's most glorious voice"

September 22, 1965

TO ALL MAINTENANCE ENGINEERS - FOR IMMEDIATE ACTION

NO. MODELS

SUBJECT: Use of standard tone cabinets with  
E-100, 200, 300 organs.

23 E-100 Series  
E-200 Series  
E-300 Series

This concerns an output circuitry revision of the tone cabinet adapter receptacle on the AO-63 amplifier, in order to render better performance when a cabinet is added to this series.

The revision involves all organs below the following serial numbers:

|             |                                |
|-------------|--------------------------------|
| E-111 #3361 | E-262 #2771                    |
| E-182 #1987 | E-311 #2712                    |
| E-133 #1483 | E-112 #3069 *                  |
| E-143 #1772 | * (except #2414 through #2422) |

Circuitry changed is the deletion of resistor R 333 (1500 ohm), capacitor C 312 (.47 Mfd.) and transformer T 302. The socket P 308, pins #1 and #5, are then wired directly across output transformer T 301 secondary, being sure to retain grounding of pin #3.

Please make these rather minor revisions and bill us for your services.

RCP/bf

NOTE: This bulletin is a confidential letter to the Hammond dealer organization and is not for general distribution.  
HAMMOND ORGAN COMPANY, 4200 W. DIVERSEY AVE., CHICAGO, ILL., 60639